

# LUTRON VIVE

## LUTRON VIVE

Introducing a revolutionary wireless lighting control solution for new and existing commercial buildings.

## Design

- Build from a full suite of products
- Combine individual fixture control and area control
- Expand the system at any time

## Install

- Less wiring for faster installation as well as reduce labor time
- Push button setup or using smart device
- Start small and expand at any time

## Maintain

- Monitor, adjust, and manage from any smart device
- Energy saving
- Minimize down time
- Expand capability
- Simple integration

## Energy-saving strategies

- Occupancy/vacancy sensing

## control

- Daylight harvesting
- Time scheduling
- Demand response
- Plug load control
- High-end trim
- Personal dimming control
- HVAC integration
- System optimization service

## **Vive wireless solutions**

- Control type support:
  - Lutron Hi-lume EcoSystem
  - 0-10V
  - Phase control
  - Switching
  - CCO
- Load type support:
  - LED
  - Incandescent/halogen
  - Fluorescent
  - MLV
  - ELV
  - CFL

## **Mounting options**

- Wallbox mount
- Ceiling mount
- Fixture mount

# Device setup

- Setup and program with Vive wireless hub
  1. Press and hold on wireless device
  2. Vive wireless hub identifies the device
  3. Connect the devices and program through any smart device
- Setup without a Vive wireless hub
  1. Press and hold wireless dimmer for 6 seconds
  2. Press and hold wireless occupancy sensor for 6 seconds
  3. Now the dimmer is connected to the occupancy sensor