

LR-HVAC-INT-XX – HVAC CONTROLLER & WIRELESS TEMPERATURE SENSOR



This is the HVAC Controller & Wireless Temperature Sensor.
Check out the RadioRA 2 collection here.

System package includes:

- 1 HVAC Controller
- 1 Wireless Temperature Sensor*
- 1 Wired Return Air Duct Sensor

LR-HVAC-PKG-WH – °F seeTEMP WALL CONTROL, HVAC CONTROLLER & WIRELESS TEMPERATURE SENSOR



The is the °F seeTEMP Wall Control, HVAC controller & Wireless

Temperature Sensor. **Check out the RadioRA 2 collection here.**

System package includes:

- 1 HVAC Controller
- 1 seeTemp Wall Display (°F) (WH)
- 1 Wireless Temperature Sensor (SW)
- 1 Wired Return Air Duct Sensor

LR-TEMP-FLSH – FLUSH MOUNT TEMPERATURE SENSOR



This is the Flush Mount Temperature Sensor. **Check out the RadioRA 2 collection here.**