

RR-T10RL-XX — RadioRA 2 TABLETOP DESIGNER KEYPAD



This is the RadioRA 2 tabletop designer keypad. RadioRA® 2 Tabletop Designer Keypads provide homeowners with a simple and elegant way to operate lights, shade / draperies, motorized screens, and many other devices. RadioRA® 2 Keypads feature large, easy-to-use buttons, plus a unique backlit engraving option that makes the Keypads readable any time of the day or night. The Keypad buttons are rounded, allowing engraving to be displayed at an upward angle, increasing readability. The versatile design of RadioRA® 2 Tabletop Designer Keypads allows them to be mounted on a wall, placed on top of a table, or used as a cordless Keypad. The Keypads can be powered by a DC adapter (see Low-Voltage Transformer spec P/N 369561, included with -RR models) or with 2 AAA batteries. **Check out the RadioRA 2 products page here.**

- At the press of a single button, lights fade ON or OFF to desired levels and shades / draperies open or close to desired positions.
- Light levels and shade / drapery positions can be fine-tuned by pressing and holding the raise / lower buttons.
- Programmable to select whole-house or single room preset levels or positions.
- Adjustable backlight intensity. Design Features
- Prepaid engraving included. Redeemable for one engraved button kit.
- Two “Wake-up” options for cordless operation: – “Wake-up and Activate” (default) – Single button press will “wake

up” and activate selected button. – “Wake-up Only” – Single button press will “wake-up” and show status. Subsequent press will activate button.

RR-T15RL-XX – RadioRA 2 TABLETOP DESIGNER KEYPAD



This is the RadioRA 2 tabletop designer keypad. RadioRA® 2 Tabletop Designer Keypads provide homeowners with a simple and elegant way to operate lights, shade / draperies, motorized screens, and many other devices. RadioRA® 2 Keypads feature large, easy-to-use buttons, plus a unique backlit engraving option that makes the Keypads readable any time of the day or night. The Keypad buttons are rounded, allowing engraving to be displayed at an upward angle, increasing readability. The versatile design of RadioRA® 2 Tabletop Designer Keypads allows them to be mounted on a wall, placed on top of a table, or used as a cordless Keypad. The Keypads can be powered by a DC adapter (see Low-Voltage Transformer spec P/N 369561, included with -RR models) or with 2 AAA batteries. **Check out the RadioRA 2 products page here.**

- At the press of a single button, lights fade ON or OFF to desired levels and shades / draperies open or close to desired positions.
- Light levels and shade / drapery positions can be fine-

- tuned by pressing and holding the raise / lower buttons.
- Programmable to select whole-house or single room preset levels or positions.
 - Adjustable backlight intensity. Design Features
 - Prepaid engraving included. Redeemable for one engraved button kit.
 - Two “Wake-up” options for cordless operation: – “Wake-up and Activate” (default) – Single button press will “wake up” and activate selected button. – “Wake-up Only” – Single button press will “wake-up” and show status. Subsequent press will activate button.
-

RR-T5RL-XX – RadioRA 2 TABLETOP DESIGNER KEYPAD



This is the RadioRA 2 tabletop designer keypad. RadioRA® 2 Tabletop Designer Keypads provide homeowners with a simple and elegant way to operate lights, shade / draperies, motorized screens, and many other devices. RadioRA® 2 Keypads feature large, easy-to-use buttons, plus a unique backlit engraving option that makes the Keypads readable any time of the day or night. The Keypad buttons are rounded, allowing engraving to be displayed at an upward angle, increasing readability. The versatile design of RadioRA® 2 Tabletop Designer Keypads allows them to be mounted on a wall, placed on top of a table, or used as a cordless Keypad. The Keypads can be powered by a

DC adapter (see Low-Voltage Transformer spec P/N 369561, included with -RR models) or with 2 AAA batteries. **Check out the RadioRA 2 products page here.**

- At the press of a single button, lights fade ON or OFF to desired levels and shades / draperies open or close to desired positions.
- Light levels and shade / drapery positions can be fine-tuned by pressing and holding the raise / lower buttons.
- Programmable to select whole-house or single room preset levels or positions.
- Adjustable backlight intensity. Design Features
- Prepaid engraving included. Redeemable for one engraved button kit.
- Two “Wake-up” options for cordless operation: “Wake-up and Activate” (default), Single button press will “wake up” and activate selected button, “Wake-up Only” – Single button press will “wake-up” and show status. Subsequent press will activate button.

RRD-H6BRL-XX – 6-BUTTON w/ RAISE/LOWER KEYPAD



This is the 6-Button w/ Raise/Lower Keypad. **Check out the RadioRA 2 products page here.**

RRD-HN1RLD-XX – 3-BUTTON W/ 2 BUTTON RAISE/LOWER HYBRID KEYPAD



This is the 3-Button w/ 2 Button Raise/Lower Hybrid Keypad.
Check out the [RadioRA 2 products page](#) here.

- Keypad buttons are programmable to select scene or room preset levels or positions.
 - At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
 - Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
 - Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
 - Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.
-

RRD-HN2RLD-XX – 2-BUTTON W/ RAISE/LOWER HYBRID KEYPAD



This is the 2-Button w/ Raise/Lower Hybrid Keypad. **Check out the RadioRA 2 products page here.**

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
- Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.

RRD-HN3BSRL-XX – 3-BUTTON SPACED W/ RAISE/LOWER HYBRID

KEYPAD



This is the 3-Button Spaced w/ Raise/Lower Hybrid Keypad. **Check out the [RadioRA 2 products page here](#).**

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
- Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.

RRD-HN3S-XX – 3-BUTTON SCENE CONTROL W/ RAISE/LOWER HYBRID KEYPAD



This is the 3-Button Scene Control w/ Raise/Lower Hybrid Keypad. **Check out the RadioRA 2 products page here.**

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
- Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.

RRD-HN4S-XX – 4 BUTTON W/ RAISE/LOWER HYBRID KEYPAD



This is the 4 Button w/ Raise/Lower Hybrid Keypad. **Check out**

the RadioRA 2 products page here.

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved Replacement Button Kit.
- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
- Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.

RRD-HN6BRL-XX – 6-BUTTON W/ RAISE/LOWER HYBRID KEYPAD



This is the 6-Button w/ Raise/Lower Hybrid Keypad. Check out the RadioRA 2 products page here.

- Keypad buttons are programmable to select scene or room preset levels or positions.
- At the press of a keypad button, lights fade ON or OFF to desired levels and shades/draperies open or close to desired positions.
- Prepaid engraving included. Redeemable for one engraved

Replacement Button Kit.

- Internal dimmer is assigned to top button by default. Tap top button to toggle load ON / OFF.
 - Internal dimmer can be assigned to any button on the C • L ® Hybrid Keypad and can be programmed to be controlled by any keypad.
-

RRT-GHXB – GRAFIKT DIMMING KEYPAD



This is the GrafikT Dimming Keypad. **Check out the RadioRA 2 products page here.**

- Hybrid keypad allows for local control of load as well as typical keypad functionality.
- Hybrid keypad will function as a normal keypad when no load is installed or load burns out.
- Custom, backlit, engraved, scene / zone descriptions on faceplate.
- Dynamic Backlighting Management (DBM) automatically adjusts the intensity of the backlit engraving to ensure text is readable in any light.
- All buttons are fully programmable, including the raise / lower functionality.
- Available in 2,4,5,& 6 button.